




Colour code	BK	Black	P	Pink
	BR	Brown	R	Red
	DBL	Dark Blue	T	Tan
	DGN	Dark Green	V	Violet
	GY	Gray	W	White
	LBL	Light Blue	Y	Yellow
	LGN	Light Green	*	With tracer
	O	Orange		



Wiring symbols



Main circuit identification codes

A1	Battery circuit to ammeter	M	Lighting circuit (interior lights)
A2	Battery circuit to ammeter	P	Brake checking circuit
B	Back-up lamp circuit	Q2	Accessory buss bar feed (fuse block)
C	Air conditioning and heater circuits	Q3	Battery buss bar feed (feed)
D	Emergency, stoplamp and turn signal circuits	R3	Alternator circuit to electronic voltage regulator (field)
E	Instrument panel cluster, switches and illumination circuits	R6	Alternator circuit to ammeter (feed)
F	Radio speakers and power seat circuits	S	Starter motor and starter relay circuit
G	Gauges and warning lamp circuits	T	Trunk lamp circuit
H	Horn circuit	V	Windshield wiper and washer circuit
J	Ignition system run circuit	W	Power window circuit
J1	Ignition switch feed circuit	X	Radio, cigar lighter, lamp grounds, clock, speed control, power antenna, deck lid and door locks
J3	Ignition switch start circuit		
L	Lighting circuit (exterior lights)		